

Stage Dimension:

A: 34ft across (Stage left to Stage Right)

B: 22ft long (Upstage Wall to Downstage Stage Lip)

C: 10ft height (Stage floor to Top of stage wall)

D: 13.3 ft height (Stage floor to Light Grid)

E: Stage Right Doorway entrance/exit (two steps to ground level)

F. Upstage Right entrance/exit (single step to ground level)

G Upstage Left entrance/exit (single step to ground level)

H: 22.5 ft across (Backstage wall Left to Right)

I: Two front steps to enter or exit stage floor from ground level